



MAINTENANCE SCHEDULE

EN1176-1:1998

The advised frequency of the following actions is for your information and guidance only. They should vary according to: the installation site, the age of the equipment and the level of usage.

PRODUCT NAME: EXOSPHERE
 PRODUCT CODE: IPO2

FREQUENCY	WHAT TO DO	WHAT TO USE	EQUIPMENT NEEDED
EVERY MONTH	Routine visual inspection to identify the risks stemming from acts of vandalism, use or specific weather conditions Inspect tightness of bolts and fixings Check for missing or broken parts Make sure that all protective covers are in place Inspect Safer Surfacing below equipment		
EVERY THREE MONTHS	Functional check to make sure that the equipment, or the part concerned is operating correctly	spares as required	
	Check all fixings, joints and stability of equipment and tighten or replace if necessary	Spares as required	
	Check all parts for wear	Spares as required	
	Thorough cleaning of equipment and any stainless steel parts	Water and detergent	High pressure cleaner Abrasive sponge
EVERY 12 MONTHS	Inspect the anchoring system		
	Inspect moving parts		
	Check overall condition of paintwork – repaint if necessary		Paintbrush



Installation and maintenance instructions should be retained by those responsible for the maintenance of the play area.

During installation and ongoing maintenance of play equipment, please check that the risk of entrapment conforms to the latest European regulations.