




Maintenance Document



Maintenance Instructions for IP12 - Wheelspin


The advised frequency of the following actions is for your information and guidance only. They should vary according to: the installation site, the age of the equipment and the level of usage. During installation and ongoing maintenance of play equipment, please check that the risk of entrapment conforms to the latest regulations.

Maintenance Required			
Frequency	What to Do	Product to use	Material to use
Every month	- Routine visual inspection to identify any risks stemming from acts of vandalism, use or unusual weather conditions. - Inspect tightness of bolts and fixings. - Check for missing or broken parts. - Make sure that all protective covers are in place. - Inspect surfacing below equipment.		
Every 3 months	- Functional check to make sure that the equipment, or part concerned is operating correctly. - Check all fixings, joints and general stability of unit and tighten or replace where necessary. - Thorough cleaning of equipment and any galvanised steel parts. - Check paint work for damage, touch up if required. - On rotation of unit listen for any abnormal noise from bearing and grease if required. - Check surfacing for excessive wear or damage. - If Subject to heavy use or vandalism; daily inspection recommended checking for loose/ dangerous parts, ground surface condition, sharp objects, missing parts, excessive wear and check cleanliness of equipment and site.	- Spares Available - Waterproof grease - Grease Nipple - Water and Detergent - High pressure cleaner - Abrasive sponge - (Paint available from Inclusive Play)	
Every 12 months	- Close off surrounding area to make safe during maintenance and apply warning signs. - Apply high grade waterproof grease to bearing at all grease points. - Refit inspection hatch and replace any bolts if damaged. - Inspect the anchoring system. - Check for smooth operation. - Check bearing for excessive wear, replace if required. - Inspect moving parts.	- Waterproof grease - Grease nipple - Spares Available	





Maintenance Instructions for IP12 - Wheelspin

Spares Available - Fixings			
ITEM NO	PART	SKU	IMAGE
A	Bolt cap A&B		
B	M10 Nyloc Nut	1781050	
C	M10 x 25mm Security	3051330	
D	M10 x 35mm CSK	2071405	
E	M10 x 30mm Security	3051340	
F	M10 x 25mm Security	2051367	



Maintenance Instructions for IP12 - Wheelspin

Spares Available - Parts		
ITEM NO	PART	IMAGE
A	HDPE Backing Panel	
B	HDPE Seat	
C	Floor Panel with Access Hatch	
D	Floor Panel	
E	Access Hatch	



Call us +44(0)131 214 1180

www.inclusiveplay.com

info@inclusiveplay.com

Maintenance Instructions for IP12 - Wheelspin

MAINTENANCE RECORDS				
Product	Date	Notes	Issues	Sign

Please send a copy of the maintenance record
to Inclusive Play at:
info@inclusiveplay.com



Call us +44(0)131 214 1180

www.inclusiveplay.com

info@inclusiveplay.com