

Maintenance Instructions - Moving Equipment



The advised frequency of the following actions is for your information and guidance only. They should vary according to: the installation site, the age of the equipment and the level of usage. During installation and ongoing maintenance of play equipment, please check that the risk of entrapment conforms to the latest European regulations.

Frequency	What to Do	Products to Use	Materials
Every month	• Routine visual inspection to identify any risks stemming from acts of vandalism, use or unusual weather conditions. • Inspect tightness of bolts and fixings. • Check for missing or broken parts. • Make sure that all protective covers are in place. • Inspect surfacing below equipment.		
Every 3 months	• Functional check to make sure that the equipment, or the part concerned is operating correctly. • Check all fixings, joints and stability of equipment and tighten or replace if necessary. • Check all parts for wear and tear. • Thorough cleaning of equipment and any galvanised steel parts.	Spares available. Pin Hex Allen Key M12. Water and detergent. High pressure cleaner abrasive sponge	
Every 12 months	• Inspect the anchoring system. • Inspect moving parts. • Check overall condition of paintwork - repaint if necessary.	Paintbrush.	

Maintenance Records - Moving Equipment

The advised frequency of the following actions is for your information and guidance only. They should vary according to: the installation site, the age of the equipment and the level of usage. During installation and ongoing maintenance of play equipment, please check that the risk of entrapment conforms to the latest European regulations.



Product	Date	Notes	Issues